

FIT CHART

MAKE	YEAR	TYPE	PART NO.
Ford	1998 and older	6' and 8' Bed	DK2UK
Ford	1999-2016	Superduty 6' or 8' Bed	DK2UFK
Ford	1997+	F150 new body	Not available
Dodge	1983 and older	6' and 8' Bed	DK2UK
Dodge	1984-1993	6' and 8' Bed	DK2UDK ¹
Dodge	1984-1993	6' and 8' Bed	DK2UDK17 ²
Dodge	1994-2002	6' Bed 8' Bed Standard Cab 8' Bed Extended Cab	DK2UDNK
Dodge	2003 and newer		Not available ⁵
Chevy/GMC	1987 and older	6' and 8' Bed	DK2UK
Chevy/GMC	1988-1998	8' Bed	DK2UCK ^{4,5}
Chevy/GMC	1988-1998	6' Bed	DK2UCSBK ⁴
Chevy/GMC	1999-2017	8' Bed	DK2UCLB99K ^{5,6,7}
Chevy/GMC	1999-2017	6' Bed	DK2UCSB99K ^{5,7}

PIERCE®

PULLING FOR YOU

PIERCE STOCK BED DUMP KIT

FIT CHART NOTES:

- 1 Distance between bed crossmembers measures 16-3/8"
- 2 Distance between bed crossmembers measures 17"
- 3 Kit not available unless you have a channel crossmember
- 4 True '88-'98 trucks have a main frame crossmember that opens up. Some GM '88-'90 models require the DK2UK due to their downward facing crossmember.
- 5 True '99 trucks have a 3" round crossmember. Some GM '99-'01 models require the DK2UCK (long beds) or DK2UCSBK (short beds) due to their upward facing crossmember.
- 6 All DK2UCLB99K kits require bed reinforcements. reinforcements included with kits.
- 7 1999 - 2017 Chevy trucks may require a fuel filler extension. Or you can shorten your filler, mount directly on the tank, and raise bed a short distance when fueling.

PIERCE Stock Bed Kits are not for use on flat beds.

For flat beds use Light Duty and Medium Duty Kits.